

ABB Motor Installation Instructions

1. First install the IDLE end bracket to the ceiling or wall at desired point.

2. Then install the MOTOR end bracket to the ceiling or wall at desired point.

3. Insert Idle SPRING LOADED end into bracket hole first.

4. Insert motor end into bracket with the tabs aligned. Then press down to lock motor in place.



For installing ABB Motor WITH 4" Flat Fascia

1. First install the flat fascia bracket to the ceiling or wall at desired point.
Make sure single tab is on the bottom.

2. Install the motor and idle brackets over the fascia brackets.



3. Install the 4" flat fascia to brackets by inserting groove on fascia to top opening on bracket.



4. Then push bottom part of Fascia towards back of shade until the bottom tab locks in place.



5. Mount the remote control cradle on the wall.

